

British and Hostile Aircraft spotter guide issued to Boy Scouts during World War I

Enlarged (actual size of each page 75mm wide x 121 mm high)



Reverse of these pages overleaf →

idesci

is said to be "go to ... r. ra.

is descending too deeply is sa
"or "vd juque"

is descending too flat and so the
word is said to be "dorny a plane"

"banking" describes the angle
by the planes when turning

Balloon Terms

A term applied to a de
on whose envelope is provide
"framework to keep it in shape"

A term applied to a de
which maintains its sh
by the assistance of a
network.

a

Definitions

I
... A flying machine hea

... The pilot or driver of an

In
... An aeroplane with two
of main planes one above

... An aeroplane with one s
planes

... The car of a balloon

A
... An enclosed shelter for
biplane

A
... Canoe - A biplane or tri
the upper planes are set
of the lower

... Canoe - An aeroplane h
ller in rear front

... An aeroplane having
rear